


# ALTRU...V

REAL SCIENCE FOR HVAC MAINTENANCE

877-787-3882

www.altruv.com

A Division of **UVDI**





For best results, install unit close to coil

To install the unit, cut a 2" hole into the desired location of duct. **Be careful to locate the position of the air conditioning coil to avoid damaging it prior to drilling.**


Next, drill out the holes required for the screws using the template. The hole size required for best fit is  $\frac{1}{8}$ ". Install Mounting plate once holes have been drilled out. The 2" hole cut in step 1 should be aligned with the large center hole on the mounting plate.

Install screws in these holes



Finally, once the Mounting plate has been secured into location; attach lamp to the Residential Air Unit and insert lamp through 2" hole. Rotate Unit till it locks into place. Plug the Residential Air unit into the power socket. Make sure LED and Light Pipe become lit once unit has been plugged in.

Use this template to install your Residential Air Treatment Device.




Unit	Replacement Bulb	Wattage
28-1000	28-3010	36
28-1010	28-3011	60

877-787-3882

www.altruv.com

**Note:**  
Smooth side to be mounted away from duct wall.



Peel Here

2x 1/8" THRU HOLES  
for (2) #10x 2" TYPE A PAN  
HEAD PHILLIPS, STEEL (included)

PN 21-1018 Rev A